


## GENERAL CARE INSTRUCTIONS

All Granqvists® gloves need to be used according to their designed purpose which is extinguishing fires. In other situations, the product will not guarantee high level of protection which can lead to a compromised product and personal injuries  
**Storage and transport:** keep away from direct sunlight, store in a cool and dry place and keep in original packaging.  
**Inspection before use:** Before every action inspection must be performed in order to check if there is any visible damage.  
Never use a damaged product

### LEATHER GLOVES



GENTLE WASH AT 40°C, DO NOT BLEACH  
DRIP-DRY (OR DRYING CABINET) . DO NOT IRON,  
DO NOT DRY CLEAN

#### GENERAL

Use slow and gentle program in 40°C.

#### DETERGENT (Recommended)

- Ecolabright Detergent M  
Ecolab AB  
Götalandsvägen 230  
125 45 Älvsjö  
Phone: +46851989623  
Mail Customer service: [order.se@ecolab.com](mailto:order.se@ecolab.com)

#### SOFTENER (Recommended)

- Lival Licker KNZ  
Tvätt & Textil System AB  
Address: Ytterbyvägen 18, 192 76 Sollentuna Phone:  
08-626 82 90

#### WASHING PROCEDURE

1. Put gloves into machine. Note the maximum weight of the machine and calculate that 1 pair weights ca 400gram.
2. Apply Detergent in the tray for main-wash. Usually this is marked with "II". (Recommended dose: 3ml/kg)  
- Most important is low alkaline value.  
- Example: 2kg of gloves = 6ml detergent
3. Apply softener. (Recommended dose: 15-30ml/kg)
4. Turn the machine on and set to delicate-wash. This program is gentler to the leather thanks to less mechanical abrasion on the gloves. The gloves are cleaned thanks to the detergent and temperature.

#### DRYING

Dry the gloves in a drying-cabinet 60°C for 240 minutes or in a warm-room over longer time.  
DO NOT TUMBLE DRY.

If possible, add some uncoloured leather wax to the gloves after drying. This adds dexterity and water repellence.

### TEXTILE GLOVES



GENTLE WASH AT 60°C, DO NOT BLEACH,  
DRIP-DRY (OR DRYING CABINET). DO NOT IRON  
DO NOT DRY CLEAN

#### GENERAL

Use similar program as used for fire suits 60°C

#### DETERGENT

Use common detergents. Avoid bleach and special detergents with high alkalinity intended for e.g. stain removal. We recommend low to medium alkalinity and a pH of < 10.5.

#### WASHING PROCEDURE

1. Put gloves into machine. Note the maximum weight of the machine and calculate that 1 pair weights ca 300gram.
2. Apply Detergent in the tray for main-wash. Usually this is marked with "II".
3. Washing temperatures should be 60° C/ 140° F, using the 'permanent press' (or similar) setting, and rinse at least twice.

#### DRYING

Dry the gloves in a drying-cabinet 60°C for 240 minutes or in a warm-room over longer time.